



Asus Q502LA Hard Drive Replacement

This guide teaches you how to replace the hard drive in an Asus Q502LA.

Written By: Joseph Sctbunio



INTRODUCTION

This guide teaches you how to replace the hard drive in an Asus Q502LA.

TOOLS:


- Essential Electronics Toolkit (1)

Step 1 — Remove bottom cover



- Remove the ten rather long Philips screws from the bottom cover.
- Use a spudger to pry the bottom cover off.

Step 2 — Remove hard drive



- Remove the four screws securing the hard drive caddy.
- Pull on the tab to remove the caddy from the laptop.
- Unscrew the four screws holding the hard drive to the caddy. You're done!

To reassemble your device, follow these instructions in reverse order.