




# Asus Q550L Heatsink & Fan Replacement

This guide teaches you how to replace the heatsink & fan in an Asus Q550L laptop.


Written By: Joseph Sctbunio



 **TOOLS:**


- Essential Electronics Toolkit (1)

## Step 1 — Remove bottom cover



- Remove the ten Torx T5 screws securing the bottom cover to the rest of the laptop.

## Step 2 — Remove heatsink & fan



- Remove the two Philips screws securing the fan.
- Remove the eight Philips screws securing the heatsink assembly.
- Clean the CPU and replacement heatsink assembly with alcohol and a Q-tip, and you're done!

To reassemble your device, follow these instructions in reverse order.