



Asus R510CA-OB01 Sticking or Unresponsive Keys

This guide shows you how to replace a key on your keyboard on a Asus R510CA-OB01.

Written By: Dominika Borakiewicz





INTRODUCTION

If your device has unlabeled, broken, or missing keys, they can be easily replaced with a new key. This guide shows you how to replace a key on your keyboard.

TOOLS:

- [Spudger](#) (1)
-

Step 1 — Sticking or Unresponsive Keys



- Slide the spudger under the key and raise each corner of the key.
- The key should pop right out.

Step 2



- When putting a new key in, make sure all the corners are in.
- Press down firmly until you hear a click.

To reassemble your device, follow these instructions in reverse order.

This document was generated on 2019-10-07 01:54:14 PM (MST).

