



Asus ROG G53SW-XT1 Back Panel Replacement

ASUS ROG G53SW-XT1 back panel replacement

Written By: scott smith



INTRODUCTION

This guide will show you how to replace the back panel on the ASUS ROG G53SW-XT1

TOOLS:

- [Spudger](#) (1)
- [Flathead 3/32" or 2.5 mm Screwdriver](#) (1)
- [Phillips #0 Screwdriver](#) (1)

Step 1 — Battery



- Unplug the power cable and flip the computer over.

Step 2




- Unlock the battery by pushing the switch to the right.

Step 3



- Push and hold the left switch, then pull the battery out.

Step 4 — Keyboard



- Insert a spudger, or plastic opening tool, into these five slots and pry upwards to pop up the keyboard.

Step 5




- Disconnect the keyboard ribbon cables from the motherboard.

Step 6 — Back Panel




- Insert your screwdriver into the locking mechanism and slide it to the left. This will unlock the hand rest and allow you to pull it free.

Step 7



- Remove the fourteen Phillips #0 screws.

Step 8



- Flip the laptop over and pull off the bottom cover.

To reassemble your device, follow these instructions in reverse order.