




Asus ROG G750JM-BS17N23 Hard Drive Replacement

Repair or replace your hard drive on the Asus ROG G750JM-BS17N23.

Written By: Tanner



INTRODUCTION

If you are having issues with low hard drive space, use this guide to replace your hard drive.

TOOLS:

- [Phillips #2 Screwdriver \(1\)](#)
- [iFixit Opening Tools \(1\)](#)

Step 1 — Back Plate



- With the computer upside down, lift up on the rubber cap on the back plate to access the captive Phillips #2 screw.

Step 2



- Retract the Phillips #2 screw until the cover is loose.

(i) The screw will not come all the way out.

Step 3





- Pry around the edges of the plate using a plastic opening tool until the plate is removed.

Step 4 — Hard Drive



- To access the hard drive, remove the back plate.

Step 5



- Remove the three 4mm Phillips #2 screws.

Step 6



- Pull back on the tab on the hard drive shield until it is clear of the screw slots. Next pull the shield out.

Step 7



- With the hard drive exposed, pull the hard drive away from the connection point and then remove the hard drive.

To reassemble your device, follow these instructions in reverse order.