




Asus ROG G751JL-BB17T29 Battery Disconnection

Prerequisite-only guide to disconnect the battery.



Written By: Adam O'Camb



INTRODUCTION

Prerequisite-only guide to disconnect the battery before further disassembly.

Step 1 — Disconnect the battery



- Pull the battery cable away from the connector in the same direction as the individual wires are running to disconnect the battery.

⚠ Pull evenly on the full width of the cable so that no individual wires are overly strained.

To reassemble your device, follow these instructions in reverse order.