



Asus Transformer Book T100TAF Camera Replacement

This guide shows you how to replace the camera board in your Asus Transformer Book T100TAF.


Written By: Corey Duff



 **TOOLS:**


- [Spudger \(1\)](#)
- [Tweezers \(1\)](#)
- [Phillips #00 Screwdriver \(1\)](#)

Step 1 — Camera





- Detach the keyboard from the screen by depressing the silver button on the tablet's hinge and pulling upwards on the tablet.

Step 2



- Insert the spudger behind the plastic backing of the tablet and then slide the spudger around the outside of the tablet, carefully releasing all internal clips.

Step 3




- Unscrew the two black screws from the camera board.

Step 4



- Set aside the two black phillips head 4.0 mm screws.

Step 5



- Using tweezers, disconnect the orange ribbon cable from the camera board by lightly pulling it up and towards the motherboard.

Step 6



- Lift the camera board away from the device.

To reassemble your device, follow these instructions in reverse order.