



# Asus UL30VT-A1 Battery Replacement

Simple steps to replacing a defective battery in your Asus UL30VT-A1.

Written By: Misael Ramos



## INTRODUCTION

Your battery seems like it does not charge? It may be time to replace it. This guide will provide a step by step walk through to access and replace your Asus UL30VT-A1 battery. To troubleshoot your device battery first check the link below.

- [Asus UL30VT-A1 Troubleshooting](#)

## Step 1 — Battery




- Flip the laptop so that you can see the back part. (As shown on the image)

## Step 2



- Identify both slide locks.
- Slide both towards the unlocked lock.
- Make sure you can see the red mark that indicates it is unlocked. (See image number two)

## Step 3



- Finally, while unlocking the right lock pull the battery. (See Image number two)
- The battery should slide out of place.

To reassemble your device, follow these instructions in reverse order.