



# Asus UL30VT-A1 Keyboard Replacement

How to properly replace your keys in your Asus UL30VT.

Written By: Pedro Gonzalez



## INTRODUCTION

If you need to replace any keys or would like to customize them, you can access this guide. For this guide, you will need a plastic opening tool this guide.

### TOOLS:

- [iFixit Opening Tools](#) (1)
- [Metal Spudger](#) (1)

## Step 1 — Keyboard




- Open up your laptop.

## Step 2



- Remove the outer layer that surrounds keys by using a metal spudger tool to pry it out.

## Step 3



- Identify what keys are damaged or the ones you will be replacing. Using a plastic opening tool, gently pry the key up.

To reassemble your device, follow these instructions in reverse order.