# Asus UL30VT-X1 Key Replacement

This guide will show how to replace keys.

Written By: Connor McKee

INTRODUCTION

This guide will show how to replace keys.

## 🔧 TOOLS:

- iFixit Opening Tools (1)

Step 1 — Key

- locate the two tabs on on the top right and left of the keyboard.

Step 2

- Use the plastic opening tool to pry open the keyboard cover.

Step 3

- Use your finger to gently pull up on individual keys until they pop off.

To reassemble your device, follow these instructions in reverse order and pop the cover back into place.

This document was generated on 2019-10-10 04:51:01 PM (MST).

© iFixit — CC BY-NC-SA   www.iFixit.com   Page 4 of 4