Asus Vivobook S500CA RAM Replacement

How to replace an Asus Vivobook S500CA's RAM.

Written By: Sydney Price

INTRODUCTION

If your computer is running slower than you would like, use this guide to replace your RAM. This model will support up to 8GB of RAM.

⚙ TOOLS:

- Phillips Head Screwdriver: Size PH1 (1)

This document was generated on 2019-09-23 06:19:27 PM (MST).

Step 1 — RAM

- Turn the device over so the back plate is facing up.

Step 2

- Use a Philips Head PH1 screwdriver to remove 10 screws around the perimeter of the back plate.

- *(i)* Place screws where they cannot be lost as they will be used to replace the back plate.

Step 3

- Remove the back plate by lifting it straight up.

Step 4

- Push away the tabs on the left and right sides of the RAM cartridge to release the cartridge.
- (i) Another pair of hands will make the process easier.

Step 5

- Slide the cartridge directly away from its housing.

www.iFixit.com