



# Asus W2W-A1 Disc Drive Replacement

Remove and replace the disc drive.

Written By: Emily Mullins



## INTRODUCTION

Remove the disc drive on your Asus W2W-A1 so that you may replace it with a new disc drive or a stick a hard drive in its place.

### TOOLS:

- [Phillips #0 Screwdriver \(1\)](#)

## Step 1 — Disc Drive



- Use a Phillips head screwdriver to remove the one 3mm screw labeled D on the back of the laptop.

## Step 2



- With that screw removed, you can now pull the disc drive out of the laptop by pulling on it in the direction that it slides.

To reassemble your device, follow these instructions in reverse order.

