



Asus X53BR HDD Replacement

Written By: fogalit



 **TOOLS:**

- **Phillips #00 Screwdriver (1)**

Step 1 — HDD



- Locate the HDD compartment bottom of the laptop

Step 2



- Remove the screw.

Step 3



- Open cover HDD.

Step 4



- Pull the label.
- Remove HDD.

To reassemble your device, follow these instructions in reverse order.