



Asus X540S notebook PC Hard drive Replacement

This guide will show you how to remove the hard drive on an Asus X540S notebook.

Written By: Padraic Hoselton



INTRODUCTION

This guide will show you how to remove the hard drive on an Asus X540S notebook.


TOOLS:

- Phillips #1 Screwdriver (1)

PARTS:


- 1 TB SSD / Upgrade Bundle (1)
- 250 GB SSD / Upgrade Bundle (1)
- 500 GB SSD / Upgrade Bundle (1)
- 2 TB SSD / Upgrade Bundle (1)

Step 1 — Asus X540S panel Disassembly



- Remove the two 15mm Philips #1 screws.
- Remove the two 12mm Philips #1 screws.
- Remove the six 9mm Philips #1 screws.

Step 2



- Lift the side of the top.
- Remove the keyboard cable.
- Remove the trackpad cable.

Step 3 — Hard drive



- Remove the one Philips #1 screw.
- Slide the hard drive out.

Step 4



- Remove the four Philips #1 screws.

To reassemble your device, follow these instructions in reverse order.