




Asus X54C-RB92 Battery Replacement

This guide will provide the steps for replacing a battery.

Written By: Julia Huang



INTRODUCTION

Does your battery seem to not hold charge? Do you think your battery needs to be changed? If so, follow these steps for changing the battery of the laptop.



TOOLS:


- [Fingers](#) (1)



PARTS:

- [Li-Polymer Battery Pack A41-K53](#) (1)

Step 1 — Battery




- Hold the laptop carefully with both hands upright

Step 2



- Push the two tabs located at both corners of the laptop, outwards using both thumbs.

Step 3



- Push the battery upwards as shown in the image for the battery to detach.

To reassemble your device, follow these instructions in reverse order.