




Written By: ZFix



---

## INTRODUCTION

How to replace Optical Drive.

\_\_\_\_\_ Video manual: \_\_\_\_\_

[video: <http://youtu.be/zRjcZQ59SSY>]

---



### TOOLS:



- [Phillips #0 Screwdriver](#) (1)
  - [Tweezers](#) (1)
  - [Utility Knife](#) (1)
  - [iFixit Opening Tools](#) (1)
-

## Step 1 — Keyboard




- Switch off the laptop and remove the battery.

## Step 2



- The Keyboard is held by 5x locking clips.
- Pick up a little the one side of the Keyboard and start opening the clips one by one.
- Disconnect the Keyboard flex cable from the mother board and remove the KB.
- [Please SUBSCRIBE to my channel ツ](#)

### Step 3 — Optical Drive



- Remove the screw.
- Pull out the SATA DVD Drive.

To reassemble your device, follow these instructions in reverse order.