



# Asus X751MA-DH01TQ Battery Replacement

How to successfully replace the battery in your Asus X751MA-DH01TQ laptop.

Written By: Lindsey Romero



## INTRODUCTION

If you're having trouble with your laptop turning on or holding a charge then you may need to change the battery. This guide will help you to replace the battery.


### **TOOLS:**

- [iFixit Opening Tools](#) (1)
- [Phillips #0 Screwdriver](#) (1)

### **PARTS:**


- [Asus X751MA Battery](#) (1)

## Step 1 — Battery



- Turn the laptop upside down and locate the ten screws holding in the plate cover.
- Remove all ten screws using a small Phillips head screwdriver.

## Step 2



- Use a plastic opening tool to pry open and separate the keyboard from the plate cover carefully.


*(i)* The actual keyboard will detach not the back cover.

## Step 3




- The battery contains wires connecting it to a circuit board. Slowly pull up and disconnect the wires from the board by pulling on the white tab.

## Step 4



- Remove the two 7mm screws holding the battery in place using a Phillips #00 screwdriver.

## Step 5



- Carefully lift the battery up out of place.

To reassemble your device, follow these instructions in reverse order.