



# Asus ZenBook UX21e Speaker Module Replacement

This guide will assist in replacing either the left or right speaker module in the Asus ZenBook UX21e.

Written By: Landon Phillips



This document was generated on 2020-01-19 09:04:53 PM (MST).

## INTRODUCTION

Removing the speaker module in the Asus ZenBook UX21e is relatively a simple process. By removing a few screws and prying off the housing, the speaker can be replaced in no time.

### TOOLS:

- [T4 Torx Screwdriver](#) (1)
- [Metal Spudger](#) (1)
- [Phillips #1 Screwdriver](#) (1)

## Step 1 — Speaker Module



- Unscrew the bottom frame cover using the T4 Torx screwdriver by removing the eight 2mm screws around the frame.
- Unscrew the two 7 mm screws at the top of the frame using the T4 Torx screwdriver.

## Step 2



- Unplug the speaker wire from the motherboard with blunt or angled tweezers.

## Step 3



- Use a metal spudger or equivalent opening tool to pry and remove the speaker housing from the frame.

To reassemble your device, follow these instructions in reverse order.