




Asus Zenbook UX31E Battery Replacement

A guide on replacing the battery in a Asus Zenbook UX31E


Written By: Hersi Dahir



 **TOOLS:**

- [iFixit Opening Tools \(1\)](#)
- [T4 Torx Screwdriver \(1\)](#)
- [Phillips #00 Screwdriver \(1\)](#)

Step 1 — Back Cover



- Using a T4 Torx screwdriver, remove the ten screws at the marked locations.



(i) Place the screws into a container as to not lose them.

Step 2




- Using your iFixit Opening Tool, carefully slide it between the back panel.
- Lift the back plate of your ASUS ZenBook UX31E and place it to the side.

Step 3 — Battery




- Disconnect the battery from the motherboard by gently pulling up and down on the connector.

Step 4



- Using the Phillips #00 screwdriver, remove the screws from the middle and the two corners of the battery.
- Place the screws into a container as to not lose them.

Step 5



- Remove the battery.

To reassemble your device, follow these instructions in reverse order.