



Asus Zenfone 3 Zoom Battery Replacement

How to remove the battery on the Asus ZenFone 3 Zoom.

Written By: Joshua Fontenelle



INTRODUCTION

This guide will demonstrate how to replace the battery of a Zenfone 3. This may be necessary if the battery has been damaged, will not hold a charge, or drains excessively quickly. For this guide, you will need the tweezers, Torx T2 screwdriver, a prying tool, and the Phillips #00 screwdriver.

TOOLS:

- [iFixit Opening Tools](#) (1)
- [Tweezers](#) (1)
- [Phillips #00 Screwdriver](#) (1)
- [T2 Torx Screwdriver](#) (1)

Step 1 — Battery




- Using a pair of tweezers, pull out the SIM card tray and set it to the side.

Step 2




- Remove the two 2 mm screws using a Torx T2 screwdriver.

Step 3




- Insert a prying tool between the screen and the metal backing of the phone at the bottom to remove backing from phone.
- There will be a thin film connecting the two pieces. You do not need to remove this. Just fold the two pieces apart with the inside facing up.

Step 4



- Remove the two 3 mm screws, using the Phillips #00 screwdriver, on the silver band at the top of the battery and remove the band.

Step 5




- Peel back the silver tape.

Step 6



- Disconnect the battery connections.

Step 7



- Pry and remove the battery.

(i) The underside of the battery is adhesive so make sure to pry the battery off gently.

To reassemble your device, follow these instructions in reverse order.