



Azpen A727 Back Cover Replacement

Removing Azpen A727 Back Cover.

Written By: lkmemphis



INTRODUCTION

Use this guide to remove the back cover of the AZ 727. This may take a little time, so do not throw the device down in disgust.

TOOLS:

- [Phillips #0 Screwdriver](#) (1)
- [iFixit Opening Tools](#) (1)

Step 1 — Back Cover



- Remove two 3mm screws with the Phillips screwdriver.

Step 2



- Insert a plastic opening tool in the center then gently work towards the center.
- Work the opening tool around the edges to separate the back cover from the rest of the device.

(i) Once the first corner props open, the rest should open easily.

To reassemble your device, follow these instructions in reverse order.