



# BLU Dash Music 4.0 SIM Card Replacement

This replacement guide will explain to you how to replace your SIM Card.

Written By: Lioma Terrero Soto



 **TOOLS:**

- [iFixit Opening Tools \(1\)](#)

 **PARTS:**

- [SIM card\(s\) \(1\)](#)

## Step 1 — Remove Back Cover



- Use the plastic opening tool or your fingernail to pry off the back cover.

## Step 2 — Remove the Battery



- Use the plastic opening tool or your fingernail to pry off the battery from the top right corner.

## Step 3 — Remove the SIM Cards



- Remove the SIM card(s) by pulling them out of their slot(s).

## Step 4 — Insert the New SIM Card(s)



- Insert the new SIM card(s) into the slot(s) by pushing them into place with the proper orientation.

To reassemble your device, follow these instructions in reverse order.