



BLU WIN HD LTE Battery Replacement

How to replace the battery of the BLU WIN HD LTE.

Written By: Taelar Tritton-Bowman




INTRODUCTION

The battery is what powers the device. The battery is secured by a sticky adhesive label and glue so be cautious when removing.

TOOLS:

- [JIS #00 Screwdriver](#) (1)
- [Spudger](#) (1)

Step 1 — Back Case



- Pry the back cover from the bottom of the phone, pulling outwards and upwards.

Step 2



- Fully remove the cover and set aside in a safe place.

Step 3 — Frame Cover



- Remove all the nine 2mm screws using the JIS #00 Screwdriver.



Step 4



- Pry the frame off using the spudger pulling upwards going to different areas around the device.

(i) The back cover is secured by glue. Removal could be more difficult than expected.

Step 5 — Battery



- Remove the battery out using the black nylon spudger.
- ⓘ Battery is secured by glue so use more force to take it out.

To reassemble your device, follow these instructions in reverse order.