



# BLU WIN HD LTE Speaker Replacement

Replace the speaker of the BLU WIN HD LTE.

Written By: Taelar Tritton-Bowman




## INTRODUCTION

The (0.7W) speaker may need to be repaired or replaced if it is not working properly.

### TOOLS:

- [JIS #00 Screwdriver](#) (1)
- [Spudger](#) (1)

## Step 1 — Back Case



- Pry the back cover from the bottom of the phone, pulling outwards and upwards.

## Step 2



- Fully remove the cover and set aside in a safe place.

## Step 3 — Frame Cover



- Remove all the nine 2mm screws using the JIS #00 Screwdriver.


## Step 4



- Pry the frame off using the spudger pulling upwards going to different areas around the device.

*(i)* The back cover is secured by glue. Removal could be more difficult than expected.

## Step 5 — Speaker



- Use the spudger to pry out the speaker from the Frame Cover.

To reassemble your device, follow these instructions in reverse order.