



BQ AQUARIS E5 Disassembly

Written By: Isaac Martín



Step 1 — Rear cover and SIM's holder




- Remove the back cover by pressing and then remove the two SIM holders.

Step 2 — Remove screws



- Remove the screws (9 in total) and lift the cover leaving the plate visible.

Step 3 — Disconnection of components



- Disconnect components with care and lift plate.

Step 4 — Complete disassembly



- Once this is done, the device would be completely disconnected and we could individually check any failure contained in the device.

To reassemble your device, follow these instructions in reverse order.