




Baby Einstein Take Along Tunes Handle Replacement

When the handle breaks off, then replace them

Written By: Shreya Sunny



INTRODUCTION

In this guide, you will learn how to remove and replace the handle with rings


TOOLS:

- Phillips #1 Screwdriver (1)
- iFixit Opening Tools (1)

PARTS:

- A handle with rings (1)

Step 1 — Handle



- Using a Philips #1 screwdriver, unscrew the four highlighted screws on the back side of the device.

Step 2



- With the help of a plastic opening tool, remove the handle of the device.

To reassemble your device, follow these instructions in reverse order.