



# Back Cover Removal

This guide will teach you how to remove the back cover of the Dell Inspiron 11-3162.

Written By: Dominic DeLong




## INTRODUCTION

This will show you how to remove the back cover of the Dell Inspiron 11-3162. This is the starting point of all our guides here, and is necessary to reach the components of your laptop.

### TOOLS:

- [Tweezers \(1\)](#)
- [Heavy-Duty Spudger \(1\)](#)
- [Phillips #00 Screwdriver \(1\)](#)

## Step 1 — Back Cover Removal



- Remove the screw cover by using tweezers.

## Step 2





- Using the phillips screw head (PH00), unscrew the 9 6.8mm philip screws.

## Step 3



- Use the regular black nylon spudger tool to pry around the base edges of the back cover and remove it.

## Step 4



- Gently pull upwards on the latch with tweezers
- When you've flipped the latch open, pull the ribbon cable outwards to disconnect the back cover from the motherboard.

To reassemble your device, follow these instructions in reverse order.