



# Back Panel

Prerequisite Only

Written By: Ryan Williams




## INTRODUCTION

This guide will help you take apart your Garmin Dezl 760LMT to reach and replace needed parts.

### TOOLS:

- [T6 Torx Screwdriver](#) (1)
- [Metal Spudger](#) (1)

## Step 1 — Back Panel



- Using a Torx T6 Screwdriver, remove the ten 7mm screws from the back panel.

## Step 2



- Using a metal spudger, pry the device apart.

 To recombine them, line up the two halves of the device and press them together.

## Step 3



- Turn the device over, laying it on its back with the screen facing upwards.
- Lift the front panel away from the silver part of the back panel.

**⚠** Make sure not to rip the ribbon cable that is connected to the screen and the motherboard.

To reassemble your device, follow these instructions in reverse order.