



Battery Replacement

Replace the battery of a Samsung Galaxy Express 3 phone.

Written By: Adrian Eaton



Step 1 — Battery



- Place the phone face-down on the table.
- Remove the back cover by lifting up on the groove in the upper-left corner of the phone.

Step 2 — Back Cover



- Run your fingers along the perimeter of the phone to pop up a corner of the back cover.
- Peel slowly to fully remove the back cover.

Step 3



- Press on the bottom of the battery and lift the battery up and out of the phone.

To reassemble your device, follow these instructions in reverse order.