



Bissell SmartClean 1605 Motor/Wheels Replacement

This replacement guide for the wheels and motor component of your Bissell 1605 Robot.

Written By: John Kroska



INTRODUCTION

If your device has stopped or slowed moving, the motor and/or tires might need to be cleaned or replaced. This replacement guide will outline the necessary steps to remove, clean, and reinstall the motor or tires component.

TOOLS:

- Phillips #2 Screwdriver (1)

PARTS:

- Right Wheel (1)
- Left Wheel (1)

Step 1 — Motor/Wheels



- Lay the Bissell 1605 on its back with the stickers on the end furthest from you.

Step 2



- Put one finger on the wheel and the other under the access cover.

Step 3



- Remove the spring and carefully pull the wires out to disconnect the wheel from the socket.

To reassemble your device, follow these instructions in reverse order.