



Black and Decker Dustbuster CHV1510 Filter Replacement

This guide will provide you with the steps necessary to replace the filter in your Black and Decker Dustbuster CHV1510.

Written By: Miguel Vilao



This document was generated on 2019-11-06 03:57:25 PM (MST).

INTRODUCTION

Replacing the filter is a tool-less process. You will be able to complete this process in fairly short time. Replacing the filter regularly ensures that your dustbuster works properly.

Step 1 — Filter



- Press the buttons with unlock symbols on both sides of the nozzle.
- Pull the nozzle upward.

(i) The other button cannot be seen on the image.

Step 2



- Press the button that reads "filter".
- Pull the blue filter cover upward.

Step 3



- Holding the blue filter cover firmly, pull filter toward you.

Step 4



- Turn the gray plastic filter clockwise and pull it upward.

To reassemble your device, follow these instructions in reverse order.