




Black and Decker Pivot MAX Battery Replacement

This guide is to replace the battery located in the main body of the Black and Decker Pivot MAX.

Written By: Jesse Sipes




INTRODUCTION

This guide is to replace the Lithium Ion battery located in the main body of the Black and Decker Pivot Max. No special tools are necessary, only a phillips screw driver is needed for this replacement.

TOOLS:

- Phillips #1 Screwdriver (1)

Step 1 — Battery



- Press in and hold the release button.
- Rotate the dust filter chamber counter-clockwise.
- Remove the dust filter chamber.

Step 2




- Remove the two 10 mm PH1 screws with the screw driver.

Step 3




- Pull the battery cover up and then slide away from the motor to remove.

Step 4



- Remove the battery unit by pulling it out of the main body.

Step 5



- Disconnect the quick connect

To reassemble your device, follow these instructions in reverse order.