



# BlackBerry Curve 8520 Battery Replacement

Learn how to remove and replace the battery of the BlackBerry 8520.

Written By: Matt



## INTRODUCTION

Remove the battery of the BlackBerry Curve 8520.



### PARTS:

- [BlackBerry Curve 8520 Battery](#) (1)

## Step 1 — Back Panel



- Insert a plastic opening tool into the small notch on the rear cover of the phone.
- Pry the rear cover up from the phone.

## Step 2 — Battery



- Locate the slit between the top of the battery and the casing.
- Gently apply pressure on the top of the battery to trigger the spring release.

To reassemble your device, follow these instructions in reverse order.