




Breville BKC600XL Water Valve Replacement

Replacing the water valve should it fail to work.

Written By: Antonio



INTRODUCTION

Replacing the water valve should it fail to work.

TOOLS:

- 1.5mm Hex Screwdriver (1)
- Phillips #0 Screwdriver (1)

Step 1 — "Bottom" Black Shell Piece



- Remove the two 12mm black Phillips screws using a Phillips #0 screwdriver.


- ▣ Reminder for reassembly; This bottom piece is first to be screwed back on.

Step 2 — "Top" Black Shell Piece



- Remove the two 12mm Phillips screws using a Phillips #0 screwdriver.

Step 3 — Silver Casing



- Remove the grey plastic casing.
- Remove the two 12mm hexagonal screws using a 1.5mm hex screwdriver.

Step 4 — Water Valve



- Cut the band connecting the hose to the water valve.
- Remove the water valve.

☞ Reminder for reassembly; You will need a new band to tie the hose back to the water valve.

To reassemble your device, follow these instructions in reverse order.