



Brother XR-40 Bobbin Replacement

This guide shows how to replace a bobbin that is broken.

Written By: Allison



INTRODUCTION

The bobbin is crucial to a functional sewing machine! This guide will take you through the steps to replace it.

Step 1 — Bobbin



- Pull off the storage area beneath the needle.

Step 2



- Flip open the tab below the needle.

Step 3



- Pull on the end of the rectangular tab on the bobbin case. This will pop off the bobbin and bobbin case.

Step 4



- Pull the bobbin out of the bobbin case.

To reassemble your device, follow these instructions in reverse order.

This document was generated on 2019-09-16 03:05:41 PM (MST).

