



# CD/DVD Drive Replacement

This will guide you in replacing the CD/DVD Drive of a Sony Vaio VPCF132FX

Written By: trickster



This document was generated on 2019-09-24 03:40:54 PM (MST).

 **TOOLS:**

- Pro Tech Toolkit (1)

## Step 1 — Battery




- Remove all wires then flip the laptop

## Step 2




- Remove the battery

## Step 3 — CD/DVD Drive



- Remove the 2 screws holding the CD/DVD Drive.

## Step 4



- Slide the CD/DVD Drive out.

To reassemble your device, follow these instructions in reverse order.