



Canon EOS Rebel G Batteries Replacement

Written By: Zach



INTRODUCTION

This guide shows you how to install new batteries.



PARTS:

- New Batteries (123 3v) (2)

Step 1 — Batteries



- Locate the battery compartment on the bottom of the camera.

Step 2



- Slide the tab on the battery cover to reveal the batteries.

Step 3



- Remove the batteries.

To reassemble your device, follow these instructions in reverse order.