



Canon EOS Rebel T1i Battery Replacement

If your camera's battery is broken or has run out of power, follow this guide to replace the battery.

Written By: Jonathan Lin



INTRODUCTION

This guide will provide you with instructions to replace your drained or broken battery.

TOOLS:

- Fingers (1)

Step 1 — Battery



- On the bottom of the device, use your fingers to push down on the latch on the battery door.

Step 2



- Completely open the battery door with your fingers.

Step 3



- Remove the existing battery with your fingers.

i The image shows a placeholder for the battery.

To reassemble your device, follow these instructions in reverse order.