



Canon EOS Rebel T1i Eyepiece Replacement

If the eyepiece, the rubber or plastic rectangular piece around the viewfinder, is loose, broken, or lost, then you should read this guide to replace it.

Written By: Jonathan Lin



INTRODUCTION

This guide will provide you with instructions to take out the existing broken eyepiece and replace with a new one.



TOOLS:

- [Fingers](#) (1)



PARTS:

- [Cannon eyepiece](#) (1)

Step 1 — Eyepiece



- If necessary, remove the rubber grip around the eyepiece by gently peeling it off.
- Use your index finger and thumb to grip the eyepiece by the sides.

Step 2



- Pinch your fingers together and wiggle the eye piece gently upwards until it is detached from the camera.

To reassemble your device, follow these instructions in reverse order.