



Canon EOS Rebel T3i Battery Replacement

Replace the battery in your Canon EOS Rebel T3i.

Written By: Natalie Crock



INTRODUCTION

Before beginning, be sure to have a replacement battery that is compatible with the camera. You will need to have a Canon LP-E8 7.4 Volt Digital Camera Battery.

Step 1 — Battery



- Locate the battery compartment on the bottom of the camera.

Step 2



- Hook your finger onto the compartment door latch.
- Open the battery compartment door.

Step 3



- Remove the battery from the compartment.

To reassemble your device, follow these instructions in reverse order.