



Casio CTK-501 Keys Replacement

This guide will show you how to remove and reinstall any stuck or broken keys on your Casio CTK-501 keyboard.

Written By: Jimmy Winne



 **TOOLS:**

- Phillips #0 Screwdriver (1)
- Phillips #2 Screwdriver (1)

 **PARTS:**

- Replacement Keys (1)

Step 1 — Bottom Panel



- Flip the keyboard upside down so the bottom is angled towards you.

Step 2




- Use a #2 Phillips screwdriver to remove the twenty-seven 12 mm screws from the dark gray bottom panel.

Step 3



- Remove the bottom panel by lifting the bottom panel up and outward from yourself.

Step 4



! Flip the entire keyboard so the keys face up, and be careful not to let the bottom drop.

- Flip the top half of the keyboard and set onto the bottom half with the internal parts facing up.

Step 5 — Keys



- Completely unscrew and remove the screws holding the broken string of keys in place.

Step 6



- Pull up the top layer of white keys to remove them from the keyboard.

Step 7



- Pull up on the last layer of white keys to remove them.

Step 8



- Push the black keys toward the front of the keyboard and rotate them until they fall out of the keyboard.

To reassemble your device, follow these instructions in reverse order.