




Casio WK-220 Buttons Replacement

Replace or clean one of the button clusters on front black panel

Written By: Alexa





INTRODUCTION

This guide will show you how to remove, clean, and replace the button clusters on the keyboard's front black panel

TOOLS:


- [Phillips #2 Screwdriver](#) (1)
- [iFixit Opening Tools](#) (1)

Step 1 — Buttons



- Place keyboard key side down
- Remove 23 16mm screws with Phillips #2 screwdriver


Step 2



- Use plastic opening tool to pry up volume knob
- Remove volume knob

This document was generated on 2019-09-26 01:02:35 AM (MST).

Step 3



- Pull black panel away from keyboard and place face-up on keys
- Remove all screws from circuit panel with Phillips #1 and #2 screwdrivers in order to remove all 18 16mm and 18mm screws.

Step 4



- Pull circuit panel away from black panel
- Set circuit panel out of the way
- Remove/clean button cluster
- Reassemble with new/cleaned button cluster

To reassemble your device, follow these instructions in reverse order.