



Chain Adjustment

How to adjust the chain of a Poulan 1.5 HP Peak 8 Amps Pole chainsaw

Written By: kempc8



INTRODUCTION

Outline what you are going to teach someone how to do.

Step 1 — Chain Adjustment



- Locate the two nuts and screws to adjust the chain saw.



YOU MAY NEED TO PULL THE BLACK INTER CASING THAT THE CHAIN GO AROUND TO TIGHT

Step 2



- USE nut driver 7/16 to loosen the nuts and realignment chain around the black casing.
- Tight the chain saw chain that it tight enough that it move around the black inter case.



YOU must have to readjust move than once.



Must have to pull the black casing forward . Readjust the nuts again.

To reassemble your device, follow these instructions in reverse order.