



Change Packard Bell memory (install)

Packard Bell Easy Note TK85-GN-008GE Change memory Install main memory

Written By: Sandro



INTRODUCTION

this repair guide will help you to swap the memory of your Packard Bell.

Step 1 — Change memory



- Turn off the laptop completely.
- Remove the two Phillips # 000 screws and remove the cover.
- Use your fingers to undo the case on the bottom.

Step 2



- To the right of the already installed RAM modules, you will find the brackets that secure the RAM in the bracket. Press the two clips outwards.
- The Ram chip folds up slightly after unlocking and can then be easily removed. Repeat this process to remove the second RAM as well.
- Insert the new RAM and press it down with a little pressure, so that the memory is back in the holder.

Repeat the steps in order to reassemble your device.