



Chromebook 14-x015wm Keyboard Replacement

This guide will show you how to replace the keyboard if it is damaged.

Written By: Michael Johnson



INTRODUCTION

This guide will show you how to replace the keyboard if it is damaged.

TOOLS:

- Pro Tech Toolkit (1)

Step 1 — Keyboard



- Turn the Chromebook upside down. Make sure to remove the small rubber circles and all four corners, and additional three other small rubber covers and proceed to unscrew the screws.


Step 2



- Flip the laptop back over and open it so that the keyboard is revealed to you. Now you are going to use a spudger to pry off the keyboard. Its slightly difficult to get off but evenly go around all four sides until it pops out.

 Be careful of the ribbons underneath that connect the keyboard to the internal components

Step 3



- Unclip the ribbons under the keyboard to disconnect it.

To reassemble your device, follow these instructions in reverse order.