



Citizen Ecodrive Watch Battery Replacement

This guide will help you replace a battery capacitor in the Ecodrive watches.

Written By: Billy Tat




INTRODUCTION

Although the Ecodrive watches made by Citizen contain a rechargeable battery, after a long period of usage the battery is no longer able to hold a charge. When that occurs, it would be less expensive to replace the battery instead of buying a new watch. This guide demonstrates how to properly perform a battery replacement on a Citizen Ecodrive watch.

TOOLS:


- [SIM Card Eject Tool](#) (1)
- [Watch wrench](#) (1)

Step 1 — Battery



- Remove pin from watch band link to obtain easier access to the back of the watch.

Step 2



- Using the adjustable wrench, unscrew the back face of the watch.

Step 3



- Using the sim removal tool, carefully pry the capacitor from its current location.

Step 4



- Replace the capacitor with the new lithium capacitor.
- Make sure the positive side is facing upward.
- When reinserting capacitor, make sure the brass connector is inserted into the inlet of the battery slot.

This document was generated on 2019-09-19 12:16:36 AM (MST).

Step 5



- Pull the knob out for thirty seconds to place the watch in its "all reset" mode.

To reassemble your device, follow the steps in reverse order.