



# Clarke Floor Sander 07012A 2012 Dust Tube Replacement

Prerequisite only guide on how to remove the dust tube on the Clarke EZ-8 floor sander

Written By: Tarun Thiruma



## Step 1 — Remove the dust bag



- Pull on the dust bag to remove it from the dust tube.
- *i* If the dust bag doesn't slide off easily, gently twist it back and forth while pulling to free it from the tube.

## Step 2 — Remove the dust tube



- Pull up on the dust tube to remove it from the sander.

To reassemble your device, follow these instructions in reverse order.