



Comfort Zone CZ6C Fan Blades Replacement

This guide is helpful if your Comfort Zone CZ6C fan blades don't spin properly. Learn how to replace your dysfunctional fan blade and/or properly clean the metal cage.

Written By: Samantha Galicinao



INTRODUCTION

Replacing your fan blade is simple and requires tools found around your household.

TOOLS:

- [WD-40 \(1\)](#)
- [Microfiber Cleaning Cloths \(1\)](#)

Step 1 — Fan Blades



- ① The metal cage is kept in place by three plastic tabs on the plastic body. Focus your pulling around these tabs to make the job easier.
- In order to remove the metal cage, place one hand firmly on the back plastic body and your other hand on the metal cage.
- Now work your way around the edge of the fan cage and pull it away from the plastic body.

Step 2



- To remove the fan blade, reach behind it and slowly pull it towards you.
- If the fan blade axle has any hair or dirt, then clean it with a cloth to avoid further fan blade blockage.
- If you are having difficulty removing the fan blade, then generously apply WD-40 to the fan blade axle.

To reassemble your device, follow these instructions in reverse order.