



Compaq Presario CQ58 WiFi, Bluetooth mini PCI card Replacement

Written By: ZFix



INTRODUCTION

How to change the WiFi mini PCI card on HP Compaq Presario CQ58.

[Please SUBSCRIBE to my channel ツ](#)


[video: <http://youtu.be/QDYm7m1AfLU>]



TOOLS:

- [Phillips #0 Screwdriver](#) (1)
 - [iFixit Opening Tools](#) (1)
-

Step 1 — WiFi, Bluetooth mini PCI card



- Disconnect the Battery.
- Remove the Memory Cover.

Step 2



- Disconnect the WiFi Antenna cable, remove the screw and you can change the WiFi mini PCI card.
- .
- Did you do it successfully?



[Please SUBSCRIBE to my channel ツ](#)

To reassemble your device, follow these instructions in reverse order.