



Compaq Presario CQ60-211DX Battery Replacement

This guide will show how to remove and replace the battery in a Compaq Presario CQ60-211DX.

Written By: Garrett Carter



INTRODUCTION

This guide will show how to remove the battery in a Compaq Presario CQ60-211DX.

TOOLS:

- Fingers (1)

Step 1 — Battery



- Turn the laptop off and disconnect all sources of power.
- Set the laptop on a flat surface with the bottom side facing up.

Step 2



- Slide the battery release tab.
- *(i)* This will eject the battery.
- Carefully remove the battery and set it aside.

To reassemble your device, follow these instructions in reverse order.